

# РЕФРИЖЕРАТОРНЫЕ ОСУШИТЕЛИ СЖАТОГО ВОЗДУХА



Архангельск (8182)63-90-72  
Астана (7172)727-132  
Астрахань (8512)99-46-04  
Барнаул (3852)73-04-60  
Белгород (4722)40-23-64  
Брянск (4832)59-03-52  
Владивосток (423)249-28-31  
Волгоград (844)278-03-48  
Вологда (8172)26-41-59  
Воронеж (473)204-51-73  
Екатеринбург (343)384-55-89  
Иваново (4932)77-34-06

Ижевск (3412)26-03-58  
Иркутск (395)279-98-46  
Казань (843)206-01-48  
Калининград (4012)72-03-81  
Калуга (4842)92-23-67  
Кемерово (3842)65-04-62  
Киров (8332)68-02-04  
Краснодар (861)203-40-90  
Красноярск (391)204-63-61  
Курск (4712)77-13-04  
Липецк (4742)52-20-81

Киргизия (996)312-96-26-47

Магнитогорск (3519)55-03-13  
Москва (495)268-04-70  
Мурманск (8152)59-64-93  
Набережные Челны (8552)20-53-41  
Нижний Новгород (831)429-08-12  
Новокузнецк (3843)20-46-81  
Новосибирск (383)227-86-73  
Омск (3812)21-46-40  
Орел (4862)44-53-42  
Оренбург (3532)37-68-04  
Пенза (8412)22-31-16

Россия (495)268-04-70

Пермь (342)205-81-47  
Ростов-на-Дону (863)308-18-15  
Рязань (4912)46-61-64  
Самара (846)206-03-16  
Санкт-Петербург (812)309-46-40  
Саратов (845)249-38-78  
Севастополь (8692)22-31-93  
Симферополь (3652)67-13-56  
Смоленск (4812)29-41-54  
Сочи (862)225-72-31  
Ставрополь (8652)20-65-13

Казахстан (772)734-952-31

Сургут (3462)77-98-35  
Тверь (4822)63-31-35  
Томск (3822)98-41-53  
Тула (4872)74-02-29  
Тюмень (3452)66-21-18  
Ульяновск (8422)24-23-59  
Уфа (347)229-48-12  
Хабаровск (4212)92-98-04  
Челябинск (351)202-03-61  
Череповец (8202)49-02-64  
Ярославль (4852)69-52-93

<https://airking.nt-rt.ru> || [ake@nt-rt.ru](mailto:ake@nt-rt.ru)

# REFRIGERATED COMPRESSED AIR DRYER

**Working Principle:** The dryer is divided into three system: heat exchange, refrigeration and electric control system. Compressed air enters the air-air or air-water pre-cooler for removing heat content, then it enters the air or air heat exchanger and being cooled down to a lower temperature. After it enters the evaporator, the air to refrigerant heat reduce the air temperature down to 2-5°C (dew point temp.), the moisture will be condensed into liquid, which will be separated by separator and be drained off by the solenoid drain valve. In the mean time, low temperature air pass throught the air to air heat exchanger, then goes to application after reaching designed temperature.

## REFRIGERATED AIR DRYER TECHNICAL PARAMETER LIST

MODEL	AH-7.5SG	AH-10SG	AH-15SG	AH-20SG	AH-30SG	AH-50SG	AH-60SG	AH-75G	AH-100G	AH-120G	AH-150GF	AH-200GF	AH-250GF	AH-300GF	AH-400GF	
Ambient temperature	≤35°C															
Air Inlet temperature	≤60°C															
Cooling mode	Air cooling															
Air flow (m³/min)	1.0	1.5	2.0	2.5	3.8	6.5	7.5	10.5	13.8	16.0	20.0	28.0	30.0	35.0	45.0	
Compressor power (KW)	0.32	0.43	0.51	0.73	0.92	1.38	1.38	1.78	2.57	2.57	2.94	4.4	4.8	5.5	7.35	
Air inlet pressure (MPa)	0.4-1.0															
Pressure loss (MPa)	≤0.02															
Dew point (°C)	2-5															
Max. pressure	13KG															
Pipe diameter	R1"					R1½"					R3"		PN1.0DN80	PN1.0DN100		
Electricity (V/ph/Hz)	220/1/50										380/3/50					
Size (mm)	L	640	640	700	730	760	900	1020	1200	1200	1200	1400	1400	1580	1730	1980
	W	380	380	390	420	450	500	610	600	600	600	730	730	900	995	995
	H	710	710	730	760	970	1120	990	1120	1270	1270	1350	1350	1760	1840	2025
Net weight (kg)	40	40	50	60	80	110	123	175	202	225	315	421	508	633	860	



Архангельск (8182)63-90-72  
 Астана (7172)727-132  
 Астрахань (8512)99-46-04  
 Барнаул (3852)73-04-60  
 Белгород (4722)40-23-64  
 Брянск (4832)59-03-52  
 Владивосток (423)249-28-31  
 Волгоград (844)278-03-48  
 Вологда (8172)26-41-59  
 Воронеж (473)204-51-73  
 Екатеринбург (343)384-55-89  
 Иваново (4932)77-34-06

Ижевск (3412)26-03-58  
 Иркутск (395)279-98-46  
 Казань (843)206-01-48  
 Калининград (4012)72-03-81  
 Калуга (4842)92-23-67  
 Кемерово (3842)65-04-62  
 Киров (8332)68-02-04  
 Краснодар (861)203-40-90  
 Красноярск (391)204-63-61  
 Курск (4712)77-13-04  
 Липецк (4742)52-20-81

Киргизия (996)312-96-26-47

Магнитогорск (3519)55-03-13  
 Москва (495)268-04-70  
 Мурманск (8152)59-64-93  
 Набережные Челны (8552)20-53-41  
 Нижний Новгород (831)429-08-12  
 Новокузнецк (3843)20-46-81  
 Новосибирск (383)227-86-73  
 Омск (3812)21-46-40  
 Орел (4862)44-53-42  
 Оренбург (3532)37-68-04  
 Пенза (8412)22-31-16

Россия (495)268-04-70

Пермь (342)205-81-47  
 Ростов-на-Дону (863)308-18-15  
 Рязань (4912)46-61-64  
 Самара (846)206-03-16  
 Санкт-Петербург (812)309-46-40  
 Саратов (845)249-38-78  
 Севастополь (8692)22-31-93  
 Симферополь (3652)67-13-56  
 Смоленск (4812)29-41-54  
 Сочи (862)225-72-31  
 Ставрополь (8652)20-65-13

Казахстан (772)734-952-31

Сургут (3462)77-98-35  
 Тверь (4822)63-31-35  
 Томск (3822)98-41-53  
 Тула (4872)74-02-29  
 Тюмень (3452)66-21-18  
 Ульяновск (8422)24-23-59  
 Уфа (347)229-48-12  
 Хабаровск (4212)92-98-04  
 Челябинск (351)202-03-61  
 Череповец (8202)49-02-64  
 Ярославль (4852)69-52-93