

АДСОРБЦИОННЫЕ ОСУШИТЕЛИ ВОЗДУХА



Архангельск (8182)63-90-72
Астана (7172)727-132
Астрахань (8512)99-46-04
Барнаул (3852)73-04-60
Белгород (4722)40-23-64
Брянск (4832)59-03-52
Владивосток (423)249-28-31
Волгоград (844)278-03-48
Вологда (8172)26-41-59
Воронеж (473)204-51-73
Екатеринбург (343)384-55-89
Иваново (4932)77-34-06

Ижевск (3412)26-03-58
Иркутск (395)279-98-46
Казань (843)206-01-48
Калининград (4012)72-03-81
Калуга (4842)92-23-67
Кемерово (3842)65-04-62
Киров (8332)68-02-04
Краснодар (861)203-40-90
Красноярск (391)204-63-61
Курск (4712)77-13-04
Липецк (4742)52-20-81

Киргизия (996)312-96-26-47

Магнитогорск (3519)55-03-13
Москва (495)268-04-70
Мурманск (8152)59-64-93
Набережные Челны (8552)20-53-41
Нижний Новгород (831)429-08-12
Новокузнецк (3843)20-46-81
Новосибирск (383)227-86-73
Омск (3812)21-46-40
Орел (4862)44-53-42
Оренбург (3532)37-68-04
Пенза (8412)22-31-16

Россия (495)268-04-70

Пермь (342)205-81-47
Ростов-на-Дону (863)308-18-15
Рязань (4912)46-61-64
Самара (846)206-03-16
Санкт-Петербург (812)309-46-40
Саратов (845)249-38-78
Севастополь (8692)22-31-93
Симферополь (3652)67-13-56
Смоленск (4812)29-41-54
Сочи (862)225-72-31
Ставрополь (8652)20-65-13

Казахстан (772)734-952-31

Сургут (3462)77-98-35
Тверь (4822)63-31-35
Томск (3822)98-41-53
Тула (4872)74-02-29
Тюмень (3452)66-21-18
Ульяновск (8422)24-23-59
Уфа (347)229-48-12
Хабаровск (4212)92-98-04
Челябинск (351)202-03-61
Череповец (8202)49-02-64
Ярославль (4852)69-52-93

ADSORPTION AIR DRYER



Attached compressed air dryer is the use of desiccation material itself unique micropores, according to the capillary adsorption of water molecules in the air, and according to the pressure release desorption and adsorption of residual heat to remove the adsorption of water. The equipment is generally made into a double-cylinder form, under the control of the program controller, two cylinders work alternately, one tube absorbs water, the other tube desorption regeneration, continuous circulation to work.

General options:

- Ambient temperature (C):** -38 -60
- Compressed air temperature (C):** +2 -50
- Cooling model:** AIR COOLING
- Loss of pressure(Mpa):** ≤ 0.02
- Dew point (C):** -40 -60
- Maximum pressure:** 13KG

Model	Flow (m ³ /min)	Pipe diameter	Dimension (mm)			Air dryer adsorbent (KG)
			L	W	H	
AH-05HL	0.8	DN15	600	350	1400	11
AH-10HL	1.5	DN15	750	450	1500	24
AH-15HL	2.0	DN20	700	500	1550	28
AH-20HL	2.6	DN20	750	500	1550	33.5
AH-30HL	3.8	DN25	800	550	1670	57
AH-40HL	5.2	DN40	1000	600	1900	90
AH-50HL	6.5	DN40	1000	700	1900	115
AH-60HL	8.5	DN40	1100	700	2100	130
AH-75HL	11.0	DN50	1100	750	2200	170
AH-100HL	14.0	DN50	1100	800	2200	200
AH-125HL	17.0	DN65	1100	800	2200	250
AH-150HL	22.0	DN65	1250	850	2400	275
AH-180HL	25.0	DN65	1300	850	2450	320
AH-200HL	28.0	DN80	1350	900	2450	400
AH-250HL	34.0	DN80	1550	900	2450	450
AH-300HL	35.0	DN80	1750	950	2500	600
AH-350HL	40.0	DN100	1750	1000	2500	700
AH-400HL	45.0	DN100	1900	1000	2550	800
AH-500HL	55.0	DN100	2100	1200	2550	1000
AH-600HL	65.0	DN125	2400	1200	2650	1200
AH-800HL	85.0	DN150	2600	1300	2900	1600



Архангельск (8182)63-90-72
Астана (7172)727-132
Астрахань (8512)99-46-04
Барнаул (3852)73-04-60
Белгород (4722)40-23-64
Брянск (4832)59-03-52
Владивосток (423)249-28-31
Волгоград (844)278-03-48
Вологда (8172)26-41-59
Воронеж (473)204-51-73
Екатеринбург (343)384-55-89
Иваново (4932)77-34-06

Ижевск (3412)26-03-58
Иркутск (395)279-98-46
Казань (843)206-01-48
Калининград (4012)72-03-81
Калуга (4842)92-23-67
Кемерово (3842)65-04-62
Киров (8332)68-02-04
Краснодар (861)203-40-90
Красноярск (391)204-63-61
Курск (4712)77-13-04
Липецк (4742)52-20-81

Магнитогорск (3519)55-03-13
Москва (495)268-04-70
Мурманск (8152)59-64-93
Набережные Челны (8552)20-53-41
Нижний Новгород (831)429-08-12
Новокузнецк (3843)20-46-81
Новосибирск (383)227-86-73
Омск (3812)21-46-40
Орел (4862)44-53-42
Оренбург (3532)37-68-04
Пенза (8412)22-31-16

Пермь (342)205-81-47
Ростов-на-Дону (863)308-18-15
Рязань (4912)46-61-64
Самара (846)206-03-16
Санкт-Петербург (812)309-46-40
Саратов (845)249-38-78
Севастополь (8692)22-31-93
Симферополь (3652)67-13-56
Смоленск (4812)29-41-54
Сочи (862)225-72-31
Ставрополь (8652)20-65-13

Сургут (3462)77-98-35
Тверь (4822)63-31-35
Томск (3822)98-41-53
Тула (4872)74-02-29
Тюмень (3452)66-21-18
Ульяновск (8422)24-23-59
Уфа (347)229-48-12
Хабаровск (4212)92-98-04
Челябинск (351)202-03-61
Череповец (8202)49-02-64
Ярославль (4852)69-52-93

Киргизия (996)312-96-26-47

Россия (495)268-04-70

Казахстан (772)734-952-31

<https://airking.nt-rt.ru> || ake@nt-rt.ru