

# РЕЗЕРВУАРЫ ДЛЯ СЖАТОГО ВОЗДУХА



Архангельск (8182)63-90-72  
Астана (7172)727-132  
Астрахань (8512)99-46-04  
Барнаул (3852)73-04-60  
Белгород (4722)40-23-64  
Брянск (4832)59-03-52  
Владивосток (423)249-28-31  
Волгоград (844)278-03-48  
Вологда (8172)26-41-59  
Воронеж (473)204-51-73  
Екатеринбург (343)384-55-89  
Иваново (4932)77-34-06

Ижевск (3412)26-03-58  
Иркутск (395)279-98-46  
Казань (843)206-01-48  
Калининград (4012)72-03-81  
Калуга (4842)92-23-67  
Кемерово (3842)65-04-62  
Киров (8332)68-02-04  
Краснодар (861)203-40-90  
Красноярск (391)204-63-61  
Курск (4712)77-13-04  
Липецк (4742)52-20-81

Киргизия (996)312-96-26-47

Магнитогорск (3519)55-03-13  
Москва (495)268-04-70  
Мурманск (8152)59-64-93  
Набережные Челны (8552)20-53-41  
Нижний Новгород (831)429-08-12  
Новокузнецк (3843)20-46-81  
Новосибирск (383)227-86-73  
Омск (3812)21-46-40  
Орел (4862)44-53-42  
Оренбург (3532)37-68-04  
Пенза (8412)22-31-16

Россия (495)268-04-70

Пермь (342)205-81-47  
Ростов-на-Дону (863)308-18-15  
Рязань (4912)46-61-64  
Самара (846)206-03-16  
Санкт-Петербург (812)309-46-40  
Саратов (845)249-38-78  
Севастополь (8692)22-31-93  
Симферополь (3652)67-13-56  
Смоленск (4812)29-41-54  
Сочи (862)225-72-31  
Ставрополь (8652)20-65-13

Казахстан (772)734-952-31

Сургут (3462)77-98-35  
Тверь (4822)63-31-35  
Томск (3822)98-41-53  
Тула (4872)74-02-29  
Тюмень (3452)66-21-18  
Ульяновск (8422)24-23-59  
Уфа (347)229-48-12  
Хабаровск (4212)92-98-04  
Челябинск (351)202-03-61  
Череповец (8202)49-02-64  
Ярославль (4852)69-52-93

<https://airking.nt-rt.ru> || [ake@nt-rt.ru](mailto:ake@nt-rt.ru)

# AIR TANK



AirKing tank is used to store compressed air, Basic ASME certificate. Can store a certain amount of air, and the output air pressure is relatively stable, at the same time can reduce the temperature in the air path, remove part of the water, dust, impurities. The gas storage tank is made of high quality materials and advanced welding technology. It has passed ISO9001 certification and can pass any safety inspection.

The air receiver plays a very important role in compressed air system with multi purposes by value of its design and the right air receive can also enhance the service life of compressor.

- 1.The air receiver stores the pressurized compressed air.
- 2.It helps to maintain constant pressure at downstream.
- 3.It cools the compressed air.
- 4.The air receiver helps to separate oil an moisture from the compressed air.
- 5.It allows the air compressor to have an optimum level of rest.



## AIR TANK PARAMETER

Air Tank				
Model	Capacity	Pressure	Size(mm)	
	(L)	(bar)	Height	Inner diameter
0.3/0.8	300	8	1594	550
0.3/1.0		10		
0.3/1.3		13	1598	
0.3/1.6		16		
0.6/0.8	600	8	1905	
0.6/1.0		10	1907	
0.6/1.3		13	1909	
0.6/1.6		16	1907	
0.6/3.0		30	1945	
1.0/0.8	1000	8	2325	800
1.0/1.0		10	2327	
1.0/1.3		13	2331	
1.0/1.6		16	2327	
1.5/0.8	1500	8	2562	900
1.5/1.0		10	2564	
1.5/1.3		13	2562	
1.5/1.6		16	2566	
2.0/0.8	2000	8	2782	1000
2.0/1.0		10	2786	
2.0/1.3		13	2782	
2.0/1.6		16	2786	
3.0/0.8	3000	8	2944	1200
3.0/1.0		10	2942	
3.0/1.3		13	2946	
3.0/1.6		16	2946	
3.0/3.0		30	3038	
4.0/0.8	4000	8	3032	1400
4.0/1.3		13	3036	
5.0/0.8	5000	8	3702	
5.0/1.0		10		
6.0/0.8	6000	8	4332	
6.0/1.0		10		
6.0/1.3		13		

Архангельск (8182)63-90-72  
 Астана (7172)727-132  
 Астрахань (8512)99-46-04  
 Барнаул (3852)73-04-60  
 Белгород (4722)40-23-64  
 Брянск (4832)59-03-52  
 Владивосток (423)249-28-31  
 Волгоград (844)278-03-48  
 Вологда (8172)26-41-59  
 Воронеж (473)204-51-73  
 Екатеринбург (343)384-55-89  
 Иваново (4932)77-34-06

Ижевск (3412)26-03-58  
 Иркутск (395)279-98-46  
 Казань (843)206-01-48  
 Калининград (4012)72-03-81  
 Калуга (4842)92-23-67  
 Кемерово (3842)65-04-62  
 Киров (8332)68-02-04  
 Краснодар (861)203-40-90  
 Красноярск (391)204-63-61  
 Курск (4712)77-13-04  
 Липецк (4742)52-20-81

Киргизия (996)312-96-26-47

Магнитогорск (3519)55-03-13  
 Москва (495)268-04-70  
 Мурманск (8152)59-64-93  
 Набережные Челны (8552)20-53-41  
 Нижний Новгород (831)429-08-12  
 Новокузнецк (3843)20-46-81  
 Новосибирск (383)227-86-73  
 Омск (3812)21-46-40  
 Орел (4862)44-53-42  
 Оренбург (3532)37-68-04  
 Пенза (8412)22-31-16

Россия (495)268-04-70

Пермь (342)205-81-47  
 Ростов-на-Дону (863)308-18-15  
 Рязань (4912)46-61-64  
 Самара (846)206-03-16  
 Санкт-Петербург (812)309-46-40  
 Саратов (845)249-38-78  
 Севастополь (8692)22-31-93  
 Симферополь (3652)67-13-56  
 Смоленск (4812)29-41-54  
 Сочи (862)225-72-31  
 Ставрополь (8652)20-65-13

Казахстан (772)734-952-31

Сургут (3462)77-98-35  
 Тверь (4822)63-31-35  
 Томск (3822)98-41-53  
 Тула (4872)74-02-29  
 Тюмень (3452)66-21-18  
 Ульяновск (8422)24-23-59  
 Уфа (347)229-48-12  
 Хабаровск (4212)92-98-04  
 Челябинск (351)202-03-61  
 Череповец (8202)49-02-64  
 Ярославль (4852)69-52-93